



# Wall Mount Change Table

Installation Guide

Models: 20-00-48 & 20-00-62

Read thoroughly before Installing



# Contents

Welcome .....	3
Technical Installation Checklist .....	5
Step-by-Step Installation Instructions .....	6
Thank You .....	11
Support and Contact Information .....	11

# Welcome

Thank you for choosing the Can-Dan Wall Mount Fold Up Change Table, designed and made in Canada to support safe, dignified, and inclusive hygiene care in public settings.

This manual contains essential instructions for the proper installation of the unit and must be reviewed in full prior to beginning any work.

Installation must be completed by qualified personnel in accordance with the procedures and specifications outlined herein. Improper installation may result in equipment malfunction, structural damage, or risk to users and caregivers.

Please read all sections of this manual carefully and follow each step precisely. If you have any questions or require clarification at any stage of the installation process, contact Can-Dan Technical Support at:  
Phone: 905-648-7522 or 1-877-5-CANDAN  
Email: [techsupport@can-dan.com](mailto:techsupport@can-dan.com)

Failure to follow these instructions may void the product warranty. For safety, performance, and compliance, ensure all installation requirements are met and documented.

# Technical Installation Checklist

## *for Solid Block Wall*

### Pre-Installation

- ✓ Confirm wall is solid concrete and structurally sound
- ✓ Structural engineer consulted (if required)
- ✓ Electrical access confirmed. 120V GFCI Power Outlet within 2 meters from the center of the unit (or hardwired by a certified electrician)
- ✓ Installation tools and hardware available
- ✓ Safety equipment in use (glasses, ear protection)

### Tools Required (Not Supplied)

- Hammer drill with masonry bits (3/8" and 5/16")
- Torque wrench
- Level
- Tape measure
- Marker or pencil
- Drill (for MDF if installing lock box)
- Vacuum or compressed air
- Adjustable/socket wrench
- Safety glasses and ear protection

# Technical Installation Checklist

## *for Solid Block Wall*

### Supplied Hardware

- 3/8" x 2" Hex Lag Bolts ×5
- 3/8" Lag Shields (Short) ×5
- 5/16" x 2" Hex Lag Bolts ×2
- 5/16" Lag Shields (Long) ×2
- 5/16" x 2" Hex Lag Bolts ×2
- 5/16" Lag Shields (Long) ×2

# Step-by-Step Installation Instructions

## Step 1 - Site Prep

- Confirm wall is solid concrete and clear the area of debris.
- Ensure electrical access (if applicable). Consult engineer if unsure.

## Step 2 - Marking & Drilling for Change Table

- Hold the unit in place and mark five (5) hole placements through the bracket.
- Use a level to ensure the unit is level.
- Set the unit aside temporarily.
- Drill each marked location using a 3/8" masonry bit to accommodate the 3/8" lag shield (short).
- Clear dust and debris from holes using a vacuum or compressed air.
- Insert Five (5) 3/8" lag shields (short) into each hole, tapping flush to the wall.

# Step-by-Step Installation

## Instructions

### Step 3 - Mounting the Change Table

- Return the unit to the wall and align the holes with the anchors in the wall.
- Insert the five (5) 3/8" x 2" lag bolts through the bracket into the installed shields.
- Hand-tighten all bolts first, then torque to approximately 20-25 ft-lbs.
- Reconfirm the unit is level and securely mounted.

### Step 4 - Installing the Locking Pin

- See the mounting diagram on Page 10 for locking pin positioning details.
- Holding the locking pin against the wall, use the two holes in the bracket to mark their positions on the wall.
- Use a level to ensure the locking pin is level.
- Drill two holes using a 5/16" masonry bit.
- Insert two 5/16" lag shields (long), flush to the wall.
- Secure the bracket using two 5/16" x 2" lag bolts.
- Torque to 20-25 ft-lbs.

# Step-by-Step Installation Instructions

## Step 5 - Installing the Lock Box

- See the mounting diagram on Page 10, figure b. for lock box positioning details.
- Mark on the inside of the lock box your desired location for the two holes.
- Drill pilot holes in the box using a 1/4" drill bit.
- Holding the lock box on the wall, mark the wall with the hole positions.
- Use a level to ensure the lock box is level.
- Drill the marked locations with a 5/16" masonry bit.
- Insert the two (2) 5/16" lag shields (long), flush to the wall.
- Attach lock box using two (2) 5/16" x 2-1/2" lag bolts.
- Torque to 20-25 ft-lbs.

# Step-by-Step Installation Instructions

## Step 6 - Perform a Full Function Test

- Plug the unit into the wall outlet.
- Ensure the tabletop folds and unfolds smoothly without obstruction.
- Confirm the side rail locks into place, in both the upright position and folded under the tabletop (if installed).
- Using the hand control, raise and lower the table to its minimum/maximum height, confirming no interference from walls, side rails (if installed), or other fixtures when adjusting the height of the change table.

When the function test is complete:

- Lower the table to its minimum height.
- Fold the side rail under the tabletop and lock it into position (if installed).
- Fold the tabletop to the upright position.
- Lock the tabletop into place using the locking pin.
- Store the hand control in the lock box.

Congratulations, your installation is complete!

Figure a.





Figure b.





## Support and Contact Info

Need help with installation, maintenance, or parts?

Phone: 905-648-7522 or 1-877-5-CANDAN

Email: [info@can-dan.com](mailto:info@can-dan.com)

Website: [www.can-dan.com](http://www.can-dan.com)

7-1469 Sandhill Drive  
Ancaster, Ontario  
L9G 0H7, Canada